



[Eucalyptus Bath Bombs Recipe](#)

Instructions (and tutorial photos) found on [AnnsEntitledLife.com](#)

Eucalyptus Bath Bombs Recipe Materials:

- 1 cup Baking Soda
- ½ cup Corn Starch
- ½ cup [Fine Grind Epsom Salts](#)
- ½ cup [Citric Acid](#) or ¼ cup of Cream of Tartar
- 15 drops [Lime Essential Oil](#)
- 10 drops [Eucalyptus Essential Oil](#)
- 1 tsp Water
- 2.5 tsp [Pure Grapeseed Oil](#)
- 5 drops Green Food Coloring

Easy DIY Peppermint Bath Bombs Utensils or Mise en Place

- Large Glass Bowl
- Small Glass Bowl or Cup
- Measuring Spoons
- Food Processor or Mixer
- Silicone Molds. These were the molds used on this project: [Sunflower Chrysanthemum Rose Mixed Mini Flower](#) and [Leaf Shape Silicone Mold](#)
- Flat Tray

Eucalyptus Bath Bombs Recipe Instructions:

- Combine the baking soda, corn starch, [fine grind Epsom salts](#) and [citric acid](#) in the large glass bowl.
- In a separate mixing bowl combine: [Lime Essential Oil](#), water, [Pure Grapeseed Oil](#), food coloring, [Eucalyptus Essential Oil](#)
- Slowly add the liquid to the dry ingredients. Combine well. Use a mixer or food processor to combine easily and well.
- When the mixture is well combined and begins to clump together spoon the Eucalyptus mixture

into the silicone molds.

- Press firmly with your fingers or the back of a spoon. This is a very important step as the tighter you pack it, the easier the bath bombs will come out when dry, and the better they will stick together.
- Allow to dry at least 24 hours. Place the silicone trays on a flat tray to move easily.
- Remove from silicone tray.
- Allow to dry on a flat tray for another day.
- To use, drop one or two Eucalyptus Bath Bombs into your bath. Enjoy the fragrance, and the soothing grapeseed oil in your bath.