



### [Coffee Bean Soy Candle](#)

Tutorial and Instructional Photos found on [AnnsEntitledLife.com](http://AnnsEntitledLife.com)

#### **Coffee Bean Soy Candle Materials:**

- 2 cups Soy Wax
- 1 Candlewick (with a weighted bottom)
- 1 8oz Mason Jar
- Candle Thermometer
- ½ tsp Vanilla Candle Scent
- Pencil
- Scissors
- Glass Measuring Cup
- 15 (or so) Whole Coffee Beans
- ½ tsp Coffee Grounds

#### **Homemade Coffee Bean Soy Candle Directions:**

- Add 2 cups of soy wax to your large glass measuring cup (do not use a plastic measuring cup) and heat in the microwave for 2-3 minutes, stirring every 30 seconds
- Stir your wax until the temperature reaches 167°F on a candle thermometer.
- Mix in the vanilla scent; stir.
- Place 6-7 whole coffee beans in the bottom of the Mason jar along with a pinch of coffee grounds.
- Dip your candlewick into the melted wax.
- Place your wax-dipped candlewick in a Mason jar allowing the bottom of the wick to drop to the bottom of the jar.
- To hold the candlewick in place, wrap the top around a pencil or chopstick or skewer.
- Place the pencil (chopstick or skewer) over the jar and let the bottom of it drop to the bottom. A weighted candlewick does this nicely and settles on its own.

- Carefully pour the melted wax into the Mason jar filling it about  $\frac{1}{4}$ - $\frac{1}{3}$  way up and then place in the freezer to freeze for approximately 20 minutes.
- Remove from freezer; add a few more whole coffee beans on top of the frozen wax and another pinch of coffee grounds. Fill another  $\frac{1}{4}$ - $\frac{1}{3}$  way up with liquid wax. Return to freezer for another 20 minutes.
- Repeat again, with whole coffee beans and coffee grounds. Again return to the freezer, this time for an hour.
- Once the mixture has hardened, remove the pencil (chopstick or skewer) and you can snip the candlewick to shorten it.

**Safety tip: never leave a lit candle unattended!**